



Sigma 24-70 Disassembly

Written By: Greg



INTRODUCTION

1°/ Remove the 4 screws on the bottom (take care because to one, the blue screw, of them is shorter than others).

Step 1 — Lens



- 1°/ Remove the 4 screws at the bottom (take care because to one of them, blue screw, is shorter than the others)

Step 2



- Remove the 4 screws around the steel ring in order to disassemble the cap (blue area) and the plastic ring (red area) which is insert inside the steel ring and behind the cap

Step 3



- Remove the steel ring (red area) due to a vertical translation (take care with the vertical sheet, in green area metal, which is used to open the diaphragm)

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 09:16:19 PM.